

# CRUX·MOTO

## 2015 – 2019 Air Release Tail Light Overlays

Thank you for purchasing our Precut Tail light overlays. These instructions will guide you through the process of installing these overlays on your vehicle. If for any reason you need some help please contact us: [Sales@cruxmoto.com](mailto:Sales@cruxmoto.com) FB.com/cruxmotorsports

Install Time: 10 mins

It is recommended that you apply these graphics in a warm space over 50 degrees Fahrenheit

What else you will need: Microfiber Towel, Rubbing Alcohol, Heat gun or hair dryer in a colder climate

For a video installation of this process please visit <https://www.youtube.com/user/CruxMotorsports> and search 2015 WRX Tail Light overlays.



Clean the light thoroughly with rubbing alcohol and microfiber towel. Make sure light is completely clean and dry before applying decal, this will ensure for a smooth dirt free application.



Once the light is clean peel the decal from the backing paper. Make sure your finger tips are also clean, the material will pick the dirt off your fingers and stick to the adhesive if they are



Align the upper right portion of the decal closest to the trunk. Leave a small overhang that at the end will be rolled over on the side of the tail lamp. Check to see if the right side of the decal looks to be aligned properly all the way down the lamp. Lightly press down on the upper right to tack the material down for the next step.



Once the right side is tacked down align the upper left of the tail light. If you are misaligned you will be able to apply a little tension to have the decal sit correctly. Do not over stretch. If the decal is too far off the right side, it is more than likely not aligned correctly.



Next, you have to push the material into the groove in the tail light. Start at the bottom right corner and use your finger tip to push the material into the groove (image 1). Once the right portion is complete move back to the lower portion starting at the corner and working your way out towards the fender (image 3). Image 2 shows what the overlay will look like once pushed into the groove.



Once the graphic is pushed into the grove, use your finger to roll any remaining decal over the edge of the tail light in towards the trunk. If applying on a cold day, you can use a heat gun or hair dryer on a low setting to heat the film for a few seconds before doing this step.

Once the driver side is applied move to the passenger side. The passenger side is applied in the same fashion as the driver side.