



2015 – 2019 X-Armor Side Skirt Paint Protection

Thank you for purchasing our Precut Tail light overlays. These instructions will guide you through the process of installing these overlays on your vehicle. If for any reason you need some help please contact us: Sales@cruxmoto.com FB.com/cruxmotorsports

Install Time: 35 mins

It is recommended that you apply these graphics in a warm space over 50 degrees Fahrenheit

What else you will need: Microfiber Towel, Rubbing Alcohol, Heat gun or hair dryer in a colder climate, Spray Bottle, Water, Clay bar kit, squeegee or bondo card.

For a video installation of this process please visit <https://www.youtube.com/user/CruxMotorsports> and search side skirt on the middle right portion of the screen.

1. In a spray bottle mix 10 parts water to one part rubbing alcohol.
2. Clean the side skirts thoroughly with rubbing alcohol and microfiber towel. Make sure side skirt is completely clean and dry before applying decal, this will ensure for a smooth dirt free application. Use your hands to feel the surface of the paint. If it feels smooth you can proceed to the next step. If it feels rough you will need to clay bar to remove surface contamination. Clay bar kits are available at a local automotive parts supply store. Follow the directions on the bottle to remove the paint contamination. It is also a good idea to wipe down the surface one more time with rubbing alcohol and a clean microfiber to make sure there is no remaining dirt or residue on the surface of the side skirt.
3. Now you are ready to apply the overlay. Pick a door to start with. In our video we will show you an installation on the driver side door. Spray down the side skirt where you are going to apply the first overlay with the water solution from the first step. Peel the overlay back from the backing paper and spray down the adhesive portion with the water mix from the first step.
4. Align the overlay in the position you want it to cover. You will be able to orient the overlay in different positions, so just make sure everything you want covered is covered before you start the next step.
5. Using a squeegee or bondo card wrapped in a microfiber, begin to squeegee out the water solution from behind the overlay. Make sure all water is squeegeed out before moving onto the next step.
6. Continue steps 3 – 5 for the next three overlays.
7. For colder climates you can use a heat gun on top of the overlay to ensure it dries faster. Just use a heat gun or hair dryer on a low setting and make some passes over the overlay.

8. **Avoid using a pressure washer or automated car wash for a few days until the overlay is completely dry.**