

CRUXMOTO

2018 – 2019 Honda Accord Air Release Tail Light Overlays

Thank you for purchasing our Precut Tail light overlays. These instructions will guide you through the process of installing these overlays on your vehicle. If for any reason you need some help please contact us: Sales@cruxmoto.com FB.com/cruxmotorsports

Install Time: 10 mins

It is recommended that you apply these graphics in a warm space over 50 degrees Fahrenheit

What else you will need: Microfiber Towel, Rubbing Alcohol, Heat gun or hair dryer in a colder climate

For a video installation of this process please visit <https://www.youtube.com/user/CruxMotorsports> and search Honda Accord Tail Light.

The following instructions are for the driver side tail lamp. To apply the passenger side, use the same instructions but mirror the positions by changing left to right or right to left.

1. Clean the light thoroughly with rubbing alcohol and microfiber towel. Make sure light is completely clean and dry before applying decal, this will ensure for a smooth dirt free application.
2. Once the light is clean, peel the decal from the backing paper. Make sure your finger tips are also clean, the material will pick the dirt off your fingers and stick to the adhesive if so.
3. Align the upper left portion of the decal furthest from the trunk. Align the decal working towards the trunk at the top. If the decal is aligned correctly work the air out from behind the decal by using a back and forth motion of your fingertips. If the decal is not aligned correctly gently pull up on the decal and realign.
4. Once the left side overlay is applied move to the trunk overlay.
5. Position longer trunk overlay first in the upper left of the lamp furthest from the center of the trunk. Align the overlay working towards the center of the trunk at the top.
6. Towards the last half inch of the overlay, apply some tension to follow the contour as it ends at the trunk's metal edge.
7. If the decal is aligned correctly work down from top to bottom in a back and forth motion with your fingertips applying pressure to push the air out from behind the overlay. If the overlay is not aligned correctly slowly pull up on the overlay and realign it.
8. The last step is to form the trunk overlay at the bottom of the trunk to roll over the edge. For warmer climates you should be able to accomplish this without any additional heat. For colder climates you will need to use a hair dryer or heat gun to warm the material up a little to conform to this curve. With a heat gun on a low setting or hair dryer, make two or three fast passes over the bottom of the lamp a few inches from the material.
9. Starting in the center of the lamp use your finger to roll the decal over the rounded edge at the bottom of the lamp.