

CRUXMOTO

2018 – 2019 Honda Accord Air Release Fog Light Overlays

Thank you for purchasing our Precut Fog light overlays. These instructions will guide you through the process of installing these overlays on your vehicle. If for any reason you need some help please contact us: Sales@cruxmoto.com FB.com/cruxmotorsports

Install Time: 10 mins

It is recommended that you apply these graphics in a warm space over 50 degrees Fahrenheit

What else you will need: Bondo card or Squeegee, Microfiber Towel, Rubbing Alcohol

This installation is a little harder than our other products it would really help if you watched our install video on YouTube! For a video installation of this process please visit:

www.youtube.com/user/CruxMotorsports and search Honda Accord Fog Light.

1. Clean the light thoroughly with rubbing alcohol and microfiber towel. Make sure light is completely clean and dry before applying decal, this will ensure for a smooth dirt free application.
2. Once the light is clean, peel the decal from the backing paper. Make sure your finger tips are also clean, the material will pick the dirt off your fingers and stick to the adhesive if so.
3. Align film starting closest to the center of the car. Once that portion is aligned keep tension on the film with your other hand and work towards the outside of the car in the center portion of the lamp only. THERE WILL BE SOME FILM OVERHANG AT THE TOP AND BOTTOM OF THE LAMP, THIS IS OKAY!
4. Once the center section of the film is tacked down all the way across the fog lamp you will want to use a bondo card or squeegee to work the film behind the fog light cover.
5. Apply gentle pressure on the lamp and it will move back away from the fog cover this will allow you to push the film down behind the cover.
6. Once the bottom is pushed behind the cover repeat the same process on the top of the lamp. When you are tucking the top of the film you should be able to apply pressure on the lamp in an in and down motion in order to tuck the film.